

Thank you for purchasing this installation kit from Intellitronix. We value our customers!

INSTALLATION GUIDE

HIGH PREFORMANCE LS IGNATION COIL Part Number: IGCL001-LS

SPECIFICATIONS

> Attachment Female/Socket

➢ Coil Style: Coil pack

➤ Coil Internal Construction: Epoxy

Coil Color: Red

> Mounting Bracket Included: No

Applications Chart

All GM based 4.8L, 5.3L, 6.0L, 6.2L, and 7.0L Engines	2006-09 Cadillac CTS-V
Chevy small block Gen III/IV LS2/3/7Coil Wire	2005-07 Buick Rainier
2005-09 Chevy Trailblazer (Including SS)	2008-09 Buick Lacrosse
2007-11 Chevy Silverado 1500/2500/3500	2005-09 GMC Envoy
2008-11 Chevy Express 1500/2500/3500	2007-11 GMC Sierra 1500/2500/3500/Denali
2005-11 Chevy Corvette	2007-11 GMC Yukon
2009-11 Chevy Colorado	2008-11 GMC Savana 1500/2500/3500
2010-11 Chevy Camaro	2009-11 GMC Canyon
2007-11 Chevy Avalanche	2008-09 Hummer H2
2006-09 Chevy Impala	2008-10 Hummer H3
2006-07 Chevy Monte Carlo SS	2005-08 Pontiac Grand Prix
2005-06 Chevy SSR	2005-06 Pontiac GTO
2007-11 Cadillac Escalade	2008-09 Pontiac G8

DIRECTIONS

- 1. Remove the coil covers (If present).
- 2. Remove the sparkplug wire from the coil.
- 3. Disconnect the factory connector, remove the coil retaining bolts and remove the coil.
- 4. Install the INTELLITRONIX coil in the same position as the original coil.
- 5. Connect the wiring harness and spark plug wire.