



**Thank you for purchasing this installation kit from Intellitronix. We value our customers!**

**INSTALLATION GUIDE**

GEN I and GEN II COYOTE OIL ADAPTER

Part Number: INTX-04



**Kit Components:**

◇ One (1) Adapter 1/4" NPT (1/8" NPT Side Port)

**INSTRUCTIONS**

- Thread the oil pressure adapter into the oil pressure port on the rear of the engine near the firewall. Tighten adapter using a 13/16" deep socket wrench. Ensure the oil pressure port is facing the direction you want the sensor to be mounted. Replace the Vehicles 1/4" Oil Sender into the end of the adapter. Crew the 1/8" Intellitronix oil sender into the 90-degree port on the side.

**Note: Be sure to test for leaks before driving the vehicle.**